

## ACS SmartAcess (for iOS)



User Guide V1.00



## **Table of Contents**

| 1.0. | Introduction | 3 |
|------|--------------|---|
| 2 0  | For iOS      | 4 |



## 1.0. Introduction

ACS SmartAccess is an application that demonstrates Access Control usage for ACS Bluetooth Readers. To fully access the application's features, connect an ACS Bluetooth Reader and use with a smart card

Supported smart card readers are ACR3901U-S1 Secure Bluetooth Contact Card Reader and ACR1255U-J1 Secure Bluetooth NFC Reader. Supported smart cards types are ACOS3 and Mifare Classic<sup>®1</sup>.

<sup>&</sup>lt;sup>1</sup> MIFARE and MIFARE Classic are trademarks of NXP B.V.



## 2.0. For iOS

- Download ACS SmartAccess app from App Store, or by clicking on the link below: https://itunes.apple.com/us/app/acs-smartaccess/id1142454409?mt=8
- 2. Turn on the Bluetooth mode of ACR3901U-S1 or ACR1255U-J1 to make it discoverable. To do this, slide the toggle switch to the right.





- 3. Turn on your device's Bluetooth by going to **Settings | Bluetooth**.
- 4. Open ACS SmartAccess app in your device.
- 5. Open the user guide by clicking on the button below. The guide can also be accessed by browsing the attachments.